



Thermal Solutions

Preventative Maintenance Schedule

Site: _____

Address: _____

City, State, Zip _____

Building Number: _____

Phone Number: _____

Contact Name: _____

Date Performed: _____

Purchase Order Number: _____

Chiller Serial Number: _____

Chiller Model Number: _____

	<u>Done</u>
Inspect and clean air filters	<input type="checkbox"/>
Inspect and clean condenser coils	<input type="checkbox"/>
Inspect water filter	<input type="checkbox"/>
Replace water filter cartridge	<input type="checkbox"/>

Done

Inspect and test for refrigeration leaks

Check water quality

Test glycol ratio (50/50 mix for outdoors)

NOTE: THE CUSTOMER IS RESPONSIBLE FOR PROVIDING GLYCOL AT THEIR COST, UNLESS A FLUID LEAK IS DETECTED IN THE CHILLER SYSTEM, RESULTING IN A LOSS OF LIQUID. CONTACT THE SERVICE DEPARTMENT WITH ANY QUESTIONS

Check fans for vibration

Check amp draw on fans, pump and compressor motors

Check the superheat (15-20 deg F)

Visually inspect for leaks, drips, and loose connections/fittings

Pull all wires in the electrical panel to check for tight connections

Materials Used:

Comments:

Customer Signature: _____

Date: _____

Contractor: _____

Address: _____

City, State, Zip _____

Phone: _____

Contractor Signature: _____

Date: _____

Please send PM schedule with invoice to ensure payment

Note: Please submit this form and Invoice to:

Dimplex Thermal Solutions

Attn: Service Coordinator

2625 Emerald Drive

Kalamzoo, MI 49001-4542

Phone: (269) 349-6800

Fax: (269) 349-8951